Naos





Manual Edition 1.0 - 11.2024





Woody Valley

Congratulations on purchasing a WOODY VALLEY product. All our products are the result of meticulous research in constant collaboration with pilots from all over the world. This is why your feedback is so important. Your experience and collaboration enable us to constantly enhance our harnesses, to always extract the maximum potential from every Woody Valley product.



MANUFACTURER'S INFORMATION:

WOODY VALLEY s.r.l. via Linz, 23 - 38121 Trento - ITALY Tel +39 0461 950811 Web: <u>www.woodyvalley.eu</u> E-mail: <u>info@woodyvalley.com</u>



	WOODY VALLEY srl Via Linz 23, 38121 Trento, TN, ITALY www.woodyvalley.com	
	Dieses Luftsportgerät wurde gemäß den rechtlichen Vorschriften stückgeprüft. Es stimmt mit dem geprüften Muster überein und ist Luftfüchtig.	
	This airsport equipment has been checked for confirmity with the legal regulations. It complies with the examined sample and is airworthy.	Dealer-distributor's-
	Stückprüfung durch: Checked by:	information
	Datum der Stückprüfung:	
	Vor Gebrauch Betriebsanweisung lesen! - Read manual before use!	
	Gurtzeug für Gleitsegel:	— Harness name
	Harness for paragliders: Nummer der Musterprüfung: Testregulation/Standards:	
Homologation load	Nachgewiesene Normen und Verfahren: Certified standards and procedures: LTF 91/09 EN1651:2015	
Production ———	Maximum load: SERIAL NUMBER	Standard reference for harness certifica-
lot	Lot of production:	tion
Size		
		Bar code
Size		Bar code
		Serial number

The label is located at the top, inside the zipper, where you will find the bridle sewn into the harness loops.

WoodyValley _____



Manufacturer's data

THANK YOU

Thank you for choosing a Woody Valley product. We invite you to carefully read the harness user manual, paying particular attention to the two most important paragraphs concerning:

INSERTING THE RESERVE PARACHUTE.

The reserve parachute is a life-saving tool, it must be in working condition when needed, whether it is used in two days or two years.

HARNESS ADJUSTMENTS.

The harness connects the pilot and the wing, enabling performance and comfort during flight. A bad, well-fitted harness can make you fly well, but a good, poorly-fitted harness can make you lose the desire to fly.

We trust that this harness will give you maximum comfort, control, performance and enjoyment in flight. We know very well that reading a user manual may not be exciting. In this case, please keep in mind that the product in question is not a juicer or a mobile phone and that the correct use of the harness greatly helps to reduce the risks of flight accidents. This manual contains all the necessary information to assemble, adjust, fly, and store your harness. A thorough understanding of your equipment enhances your personal safety and enables you to maximize your potential.

The Woody Valley Team

SAFETY NOTE

By purchasing Woody Valley equipment, you acknowledge that you are a qualified paraglider pilot and accept all risks associated with paragliding, including injury and death. The improper or incorrect use of this equipment significantly increases the risk. Under no circumstances will Woody Valley or the Woody Valley equipment retailer accept liability for personal injuries caused to yourself or to third parties, or damages of any kind. If you have any questions regarding the use of our equipment, we recommend contacting your local dealer or Woody Valley directly.



INDEX

- 1- GENERAL INFORMATION
 - 1.1 Concept
 - 1.2 T- Lock security system
 - 1.3 Protection and safety
- 2 BEFORE USE
 - 2.1 Reserve parachute
 - 2.1.1 Refolding the parachute into the deployment bag
 - 2.1.2 Connecting the reserve parachute to the harness
 - 2.1.3 Inserting the reserve parachute
 - 2.1.4 Compatible reserve parachutes
 - 2.1.5 Extracting the reserve parachute
 - 2.2 Harness adjustments
 - 2.2.1 Back adjustment
 - 2.2.2 Shoulder strap adjustment
 - 2.2.3 Chest strap adjustment
 - 2.2.4 Seat height adjustment
- 3- FLYING WITH NAOS
 - 3.1 Preflight checks
 - 3.2 Pockets
 - 3.3 CamelBak
 - 3.4 Flying tandem
 - 3.5 Flying over water
 - 3.6 Towing hook
 - 3.7 Landing with NAOS
 - 3.8 Disposal of the harness
 - 3.9 Rules of behavior in natural environments
 - 3.10 Connecting the wing
- 4- FOLDING THE HARNESS
- 5 MOUNTING AND ADJUSTING THE SPEED-BAR 5.1 - Relax bar
- 6- MAINTENANCE AND REPAIR
- 7 WARRANTY
- 8 CERTIFICATION DOCUMENTS
- 9 TECHNICAL DATA



1- GENERAL INFORMATION

This manual is an integral part of the NAOS harness and must be kept carefully for future reference.

If you would like further information, contact your dealer or Woody Valley directly.

It is recommended that the pilot carefully reads this manual before using the harness.

Declaration of conformity

The manufacturer WOODY VALLEY Ltd hereby declares that its products comply with the UNI EN 1651 - LTF 91-09 - CE 2016/425 standards.


This equipment must contain:

Harness

- Carabiners
- Polypropylene seat with flexible front part
- Rescue handle with integrated deployment bag
- Protection (foam or inflatable)
- Speed bar
- 2 elastic loops for securing the emergency parachute flap
- 2 side shields and one back shield for impact absorption.
- 2 foam elements for added comfort.

The main available options are:

- Relax bar
- Radio pocket





1.1 - Concept

The NAOS is a Harness designed for paragliding and certified for a maximum weight of 120 kg.

NAOS was designed with the aim of having a harness where the safety and comfort of the pilot are the priority.

A new passive safety system protects the pilot with shields that absorb impact, providing enhanced protection for the back and pelvis. These shields are positioned on the sides and along the entire back.

The innovative strap geometry, combined with the T-LOCK system, has been designed to simplify harness fastening and ensure precise, smooth maneuverability. Additionally, the T-LOCK acts as an anti-forgetting system so the pilot does not forget to fasten the harness.

Carefully designed in every detail, NAOS offers excellent in-flight comfort and can be adapted to both novice and experienced pilots who do not compromise on safety.

1.2 - T-Lock security system

The leg strap and chest strap are equipped with the "T-LOCK system," a safety system designed so the pilot does not forget to fasten the leg straps. This system prevents the pilot from slipping out of the harness in case they forget to fasten the leg straps.

To secure the harness, first fasten the buckles on the leg straps, then attach the central buckle on the chest strap.

This operation, though simple, must be performed and checked carefully to ensure a safe flight.





1.3 - Protection and safety

NAOS is equipped with back protection, approved according to EN-LTF standards, positioned underneath the seat. This protection can be either FOAM-based or INFLATABLE, depending on your choice; both options have certification test results below 30g.



Certificate of homologation for the protection.

AIR TURQUOISE SA | PARA-TEST.COM Test laboratory for paragliders, paraglider harnesses

Woody Valley srl Simone Caldana Via Linz 23 38121 Trento Italy

NAOS

Harness Impact Pad Report

Inspection certificate number: MISC 289.2024

Manufacturer data:

Manufacturer name: Representative: Street: Post code place: Country:

Atmosphere AGL Temp. [C*] 24 R.H. [%] 54 Press. [hPa] 1008

Summary of Impact pad test (1)

 Test Id
 Test configuration⁽²⁾

 P
 V
 Test sample attached to dummy in flying position, without emergency parachute

 PR
 V
 Test sample attached to dummy in flying position, including emergency parachute

Harness model:



Sample data:

Name impact pad: Impact pad intgrated: Impact pad type: Weight of sample [kg]: Serial number: Date of test:

 $\begin{array}{c|c} \mbox{Max Peak of} & \mbox{Duration at 38 [g]} & \mbox{Duration at 20} & \mbox{Diff. of test 1} \\ \mbox{Impact [g]}^{(2)} & \mbox{in [ms]}^{(4)} & \mbox{[g] in [ms]}^{(5)} & \mbox{and 2 [\%]} \end{array} \end{array}$

18.33

17.50

0.00

0.00

28.67


29.17

AIR TURQUOISE SA | PARA-TEST.COM Provide de i Pré-aux-Comte 8 * CH-1844 Villeneuve * +41 (O)21 955 65 65 Test laboratory for paragliders, paraglider harnesses and paraglider reserve parachutes



on certificate number: MISC_289.2024







The validation of this test report is given by the signature of the test manager on the inspection Certificate no 94 20a or 94 20b Air Turquetes SA, has theorogity tested the sample metriconed above and certifies its conformity with the following standards: NEL 2684-52 and EME(515)219-11202¹⁷

and have and provide the solar results of the solar solar (p) has a solar (p) have a solar (p) have been appending of the solar solar (p) have been appending of the solar (p) have been appendin

6



ISO 94.22

AIR TURQUOISE SA | PARA-TEST.COM



Rev 08 | 08.11.2023



Harness Impact Pad Report

spection certificate number: MISC_288.2024					
Manufacturer data:					
Manufacturer name:	Woody Valley srl				
Representative:	Simone Caldana				
Street:	Via Linz 23				
Post code place:	38121 Trento				
Country:	Italy				
Harness model:	NAOS				

Sample data: Name impact pad: Impact pad intgrated ole [ka

NAOS INFLATABLE M No Inflatable 0.41 00001 29.08.2024



Summary of Impact pad test (1)


Test id	-	Test configuration (2)	Max Peak of Impact [g] (3)	Duration at 38 [g] in [ms] (4)	Duration at 20 [g] in [ms] ⁽⁵⁾	Diff. of test 1 and 2 [%] (6)	Result
Р	v	Test sample attached to dummy in flying position, without emergency parachute	29.36	0.00	19.17	1.77	POSITIVE
PR	v	Test sample attached to dummy in flying position, Including emergency parachute	29.49	0.00	18.33	1.18	POSITIVE

Validity Calibration 23.08.2028 18.06.2025 Type no 89010-100 Manufacturer Instrument Burster/MTS Accelerometer 100 g S/N 1263567 Unit11


ion of this test report is ise SA, has them...... ed the sample mentioned above and certifies i NfL 2-565-20 and EN1651:2018+A1:2020⁷⁷

In this highth include the value where the according (i) such what). The uncertainty stated is the expended increationly detailed by nulliphy-anomicality by the concept lact is 4.2. The value of the measured is within the accepted in age of where with a pradably of 2053, in the line intermed one of the measured is the state of the state of the concertainty accepted in age of where with the pradably of 2053, in the line intermed one of the line s the expanded uncertainty obtained by multiplying the stan range of values with a probability of 95% neasure distance from bottom of impact pad to ground

Page 1 of 2







Page 2 of 2



Result

POSITIVE


POSITIVE

1 00001 29.08.2024

6.23

1.45







Page 2 of 2

· -41 (0)21 965 65 65



Name impact pad: NAOS INFLATABLE M



AIR TURQUOISE SA | PARA-TEST.COM

Test laboratory for paragliders, paraglider harnesses and paraglider reserve parachutes Inspection certificate number: MISC_288.2024

> ergency parachute P2 29.36 0.00 19.17 1.23 101.77

ding emergency parac PR2 29.49 0.00 18.33 1.24 PR1 29.14 0.00 18.33 1.22 100.00 1.24 101.18

______ 20g

inclu






ISO 94.22 Rev 08 I 08.11.2023



Rev 08 | 08.11.2023



ISO 94.22




We recommend removing the protection to inspect it after a particularly hard impact or to allow it to dry in case of a water landing. To access the back protection compartment, open the zipper at the rear and remove the protection. To reinstall it, follow the steps in reverse, ensuring the zipper is fully closed.






To remove the inflatable protection, follow the same procedure as for the foam protection. When reinstalling, ensure that the inflation tube is inserted into the hole inside the compartment first, with the white nozzle facing the front of the harness, as shown in the images.

Then, make sure to insert the end with the blue cap into the red elastic loop.





Additionally, there are two foam supports to enhance comfort and provide extra protection for the pilot's back and legs. Remove these supports to let them dry in case of a water landing.



The back support is housed in the side zipper inside the main rear compartment.



The foam support for the legs is located in the zipper inside the main protection compartment. To access it, you must first remove the protection.




When reinstalling these supports, ensure that the angled side faces outward from the harness, while the flat side faces the pilot.



NAOS also includes an innovative shield system made of high-density foam, specifically designed to absorb impacts and provide additional protection for the pilot.

These elements are positioned to protect the pelvis, thighs, and spine from accidental impacts.

With a density of 180 kg/m $\,$, it's an excellent material for impact absorption. It's also used in protective gear for motorcyclists and meets EN 1621-1 standards for body protection.




Some of these elements are fixed in the lower back area of the base and cannot be removed. In contrast, the side and back shields, which are integrated into the harness's sides and backrest, can be removed if needed. To remove the back shield, access it through the reserve bridle passage by opening the Velcro at the top. There, you will find a pocket secured with a zipper, where the shield is stored.

The side shells for protecting the legs are located in the pockets on either side of the seat.





NAOS - User Manual







2- PRIOR TO USE

2.1- Reserve parachute

The reserve parachute compartment is designed with a maximum volume of 5.6 liters, suitable for accommodating the most common models available on the market.

The container goes under the seat and it is necessary and mandatory to use specific inner bag with the handle included in the harness at the time of purchase.

No other type of inner bag and/or deployment handle can be used.

2.1.1- Refolding the emergency parachute in the inner bag

NAOS comes with a deployment bag with an attached rescue handle. Fold the reserve parachute to fit the dimensions of the inner bag. Refold the reserve parachute lines on the side opposite the deployment handle. Close the inner bag flaps.



ATTENTION:

Ask a flight instructor or a qualified person for help refolding the emergency parachute in the inner bag.




2.1.2- Connecting the reserve parachute to the harness

There are three methods for connecting the emergency parachute bridle to the harness risers.

First system:

Use a maillon with a screw lock and a breaking strength of at least 2400 kg. In this case, the bridle lines must be secured inside the maillon using elastic bands to prevent its rotation, which could result in a dangerous lateral load. The screw lock must be tightened firmly to prevent accidental opening. This type of connection can absorb a higher opening shock than the second system, and for this reason it is the recommended system.





Second system:

The harness bridle should pass through the emergency parachute bridle loop. The reserve parachute itself is then passed through its own webbing loop. This connects the two bridles.

The connection should be tightened as much as possible, in order to avoid dangerous friction between the two lines during the opening shock of the emergency.



Third system:

If you are using a reserve parachute with directional control and dual bridle, or if your reserve parachute has a double -riser bridle, it can be connected to the harness using the two loops positioned at the base of the harness bridle, near the padded shoulder straps. In this case, the harness's reserve parachute bridle will not be used, and so it should be folded, fastened using two elastic bands, and positioned under the cover behind the pilot's neck.





The two connections should be made using maillons with a breaking strength of at least 1,400 kg. In all cases, it is important to check that the length of the bridle line is sufficient to position the reserve parachute inside the harness's built-in container with enough slack to allow for the extraction of the reserve parachute without causing the deployment of the launch bag during extraction.

WARNING:


To prevent abnormal side loads, the bridles must be hooked to both loops on their respective shoulder-straps. Not only to one of the two. Do not put any objects inside the bridle container.



2.1.3- Inserting the reserve parachute

Insert the parachute in the harness container with the handle visible toward the outside and with the lines facing downward.

Introduce a thin cord (paragliding line or plastic strimmer cord type) into each elastic loop which you will use to help close the container.






Move the slider of the riser cover and the second zipper, which closes the front end, all the way to the edging located beneath the flap. Close the zipper on both sides for approximately 10 cm.

Insert the two yellow plastic pins of the handle into the upper holes of the flap, and then into the elastic loops threaded through the eyelets.

Secure the pins by inserting them into the holes on the flap and the redstitched holes on the harness at the corresponding points. Ensure that the pins are properly inserted into their designated holders and aligned with the zipper.



After securing all parts of the container, it is recommended to check that the two zippers located beneath the opening system are properly closed. It is essential that the cord is removed at the end of this step. It must be extracted slowly in order to avoid damaging the elastic loops due to excessive friction between the parts.

At the end the two zips should be completely closed and the zips stowed under the cover at the opposite end.

NAOS - User Manual



WARNING:

Any new combination of reserve parachute and harness being used together for the first time must be checked by an official harness or reserve dealer or a flight instructor, to check its effective extractability. The verification must be carried out hanging from a flight simulator, the reserve parachute extraction must be perfectly possible in the normal flight position.

The paragliding harness and reserve parachute deployment system is not suitable for use in free fall or with strong shocks.

Its bearing structure is designed, tested, and approved to withstand the opening shock of the reserve parachute, according to the standards required for paragliding flight.

This does not mean that other parts of the harness may not suffer damage due to the opening shock of the reserve parachute.

Whether this happens in the event of an actual accident or voluntarily, such as during a safety course.

2.1.4 - Compatible reserve parachutes

The volume of the emergency parachute must be less than 5.6 liters.







2.1.5- Deploying the reserve parachute

It is important to periodically locate the position of the reserve handle during normal flights to ensure instinctive reaction in emergency situations. In the event of an emergency situation, the deployment procedure is as follows:

• Search for the extraction handle and grip it firmly with one hand.

• Pull the handle outwards to extract the reserve parachute from the harness pocket.

• Find an open space, and in one smooth motion, throw the reserve parachute away from you and the wing.

• After opening, to prevent the paraglider from interfering with the reserve parachute:

- if the leading edge is facing upwards, grab the "D" risers or the brakes to collapse your paraglider;

- If the wing has the leading edge facing down, pull a riser or a brake to rotate the wing so that the leading edge faces up. Then, subsequently, pull both brakes or risers to more easily collapse your paraglider.

When landing, assume an upright position with your body and use a "parachute landing technique" to reduce the risk of injury.

After each parachute deployment, the harness must be inspected by a qualified person.







2.2 - Harness adjustments


NAOS offers the possibility of adjusting the back inclination, the chest width and the shoulder height in order to guarantee optimum position for the pilot. Finding this optimum position may take some time, but the resulting exceptional flying comfort is well worth the effort.

The NAOS is delivered adjusted to an ergonomic standard, except for the adjustments that are influenced by the height of the pilot. For the first flight, we recommend only adjusting these last settings, leaving the other adjustments unchanged, which have proved satisfactory for the majority of pilots. If you wish to change the other settings, remember that you can always return to the factory settings by making reference to the red marks on all adjustment straps.



Before making any adjustments, the emergency parachute must be inserted. To find the optimal position, we recommend hanging in the harness, simulating the flying position and conditions. Therefore, it is better to insert all the material that you normally take with you on a flight into the rear pocket.









2.2.1 - Adjustment of the back

This adjustment allows you to select the inclination of the torso with respect to the vertical flight axis.



2.2.2 - Shoulder strap adjustment

The adjustment of the shoulder straps compensates for the pilot's height variation and the adjustment buckle is located at the apex of the shoulder straps. The shoulder straps also support some of the weight of the torso for improved comfort.

Adjust the shoulder straps so they are in contact with your shoulders without being too loose or too tight.





At shoulder strap height, there is a clip that acts as a shoulder strap fastener and prevents the shoulder straps from sliding off the shoulders during take-off. The plastic clip is also a whistle which can be useful in the event of an emergency.



2.2.3- Chest strap adjustment

The chest strap controls the distance between the two carabiners, which can vary from 37 to 49 centimetres. For the first flight, we suggest setting the chest strap to around 40 cm and then locating the preferred length in flight by means of gradual adjustment.

Remember that a tighter chest strap provides greater stability. An excessive opening does not improve the performance of the wing, and an excessive closure can accentuate the effect of a possible "twist"; following an asymmetric closure of the wing.



2.2.4 - Seat Height Adjustment

This adjustment changes the angle between the thighs and the back (seat depth), distributing the load between the seat and the lumbar support, thereby enhancing the pilot's comfort.



WARNING: Each adjustment must be performed symmetrically on both sides.



3- FLYING WITH NAOS

3.1- Pre-flight checks

For maximum safety, utilize a reliable and comprehensive pre-flight check procedure, and consistently repeat the same mental sequences prior to each flight.

Check that:

- The reserve parachute handle is correctly locked in position and the pins are firmly engaged.

- Pockets and zips are closed

- All buckles are properly closed.

- Make sure that the paraglider is properly attached to the harness using the main carabiners, which must be securely closed using their respective locking mechanisms.

- The speed-bar is correctly mounted on the glider.

After careful assessment that the weather conditions are favorable for flying, put on the harness.

As shown in the photos below, to secure the harness, start by sliding your arms through the shoulder straps. Then, take the leg straps and fasten the buckles on both the right and left sides. Finally, attach the central buckle of the chest strap.





3.2- Pockets

NAOS has a spacious rear pocket that can be used to store the backpack, concertina bag, or clothing.


It also includes a pocket for storing a CamelBak and a small pocket for a wallet or keys. On the sides of the harness, there are two elastic mesh pockets with security loops and zippers to securely store your belongings.





3.3- CamelBak

NAOS is designed to accommodate the use of a CamelBak or similar hydration systems. Before takeoff, place the CamelBak inside the rear pocket, threading the tube through the plastic oval at the top of the pocket. Then, pass the tube under the two elastic straps on the left shoulder strap, as shown in the photo.





3.4- Flying in tandem

NAOS is not suitable for tandem flights.

3.5- Flying over water

NAOS is not recommended for flights over water. In the event of a forced water landing, there is a risk that the air-filled protection could keep the pilot submerged.

Woody Valley recommends using a suitable life jacket when flying over water.

3.6- Towing hook

NAOS is suitable for tow-launching. The tow bridle release should be hooked directly to the main carabiners, ensuring that the carabiners are positioned with the opening gate facing the rear. For further details, refer to the documentation provided with your tow release or consult a qualified towing instructor at your flying site.

3.7 - Landing with NAOS

Before landing, slide your legs out of the harness so that you adopt an upright position. Never land in the seated position; it is very dangerous for your back even if you have foam dorsal protection, which provides exclusively passive protection. Standing up before landing is an active safety precaution, and it is much more effective than passive forms of protection.

3.8- Disposal of the harness

Proper disposal is required for the materials used in paragliding equipment. It is recommended to return the equipment to us at the end of its life. We will then properly dispose of the harnesses.

3.9- Rules of behavior in natural environments

It is recommended to respect nature and the landscapes that surround us when we practice our sport. Do not leave the marked trails, do not litter, avoid making excessive noise, and respect the delicate balance that exists among the mountains.

3.10 - Wing Attachment

To open the carabiners, rotate the aluminium bar approximately 90°. This carabiner model is self-locking and automatically closes as soon as the lever is released.

Properly attach the wing risers to the carabiners and ensure the carabiners are securely closed.



4- FOLDING THE HARNESS

NAOS has been designed to be easily folded onto itself, despite the foam protections and impact-absorbing shells.







5 - MOUNTING AND ADJUSTING THE SPEED-BAR

NAOS is equipped with a two-step speed bar but is compatible with all common types of speed systems. After finding the optimal adjustment of the harness based on the pilot's physical characteristics, the speed bar length should be adjusted.

The speed bar cords should be passed first through the rings fixed to the elastic in front of the board, then in the harness through the eyelets near the front corners of the seat, then through the pulleys located near the rear corners of the seat. Next, take the elastic cord and tie it with a knot in the speed bar loop. Pass it through the eyelet, then through the red loop behind the back, threading it through the eyelet on the other side. Finally, tie the elastic cord to the loop on the speed bar.

For proper adjustment, one must hang from a simulator, also hang from the paraglider's shoulder straps, and with the help of a friend holding the shoulder straps, adjust the length of the speed-system's cords. When released, the speed bar must be at a distance no greater than 10 cm below the front part of the harness. Adjusting the line too short could lead to having the speed-system constantly pulled and unintentionally engaged during flight. For safety, lengthen the speed-bar slightly and progressively shorten it during subsequent flights. Please remember to make all adjustments symmetrically on both sides.





5.1- Relax Bar

All our harnesses can be equipped with a dedicated relax bar, except for those models where it is already integrated. The Relax Bar is used to keep the legs extended and the feet supported. This flying position is considered by some pilots to be more comfortable than the classic sitting position with dangling feet.

For assembly on the harness, follow the instructions in the manual enclosed with the relax-bar.





6- MAINTENANCE AND REPAIR

Check the harness after each impact, rough landing or take-off, or if there is any sign of damage or excessive wear.

We recommend having your harness checked by your dealer every two years and replacing the main carabiners every five years.

To prevent premature aging of the harness, avoid dragging it on the ground, rocks, or abrasive surfaces. Avoid any unnecessary exposure to UV rays (sun) which is not required for regular flying activities. Avoid exposure to moisture and heat whenever possible.

Store all flight equipment in a dry and cool place; do not store when damp or wet.

Regularly brush off dirt from your harness using a plastic bristle brush and/ or a damp cloth to keep it clean. If the harness is exceptionally dirty, clean it with mild soap and water.

Allow the harness to dry naturally in a well-ventilated area, away from direct sunlight.

If your reserve parachute becomes wet (e.g., landing in water), you must detach it from the harness, allow it to dry, and fold it before storing it back in its designated container.

Only the manufacturer or authorized individuals can perform repairs and replacements of harness parts using materials and techniques that guarantee the product's functionality and compliance with certification.

Keep the quick releases and zippers clean and lubricated with silicone spray. For any maintenance requests, whether through an authorized dealer or Woody Valley, please provide the complete identification number found on the silver label located in the storage pocket behind the shoulder straps. Proper use will extend the life of the harness.

In case of damage to the harness, repairs can only be carried out by the manufacturer or by workshops certified by the manufacturer.

We strongly recommend paying the utmost attention to the way of use and storage. Correct use will prolong the life of the harness.

We wish you great flights and happy landings with NAOS!







7- WARRANTY

The 2-year warranty period required by law obliges us to correct any construction defects in our products that can be attributed to manufacturing defects.

We recommend validating your warranty by completing the form available on our website in the "Support" section within 10 days of purchase. Make sure to enter the harness identification code found on the silver label located in the storage pocket behind the shoulder straps.

To initiate a warranty claim, immediately inform WOODY VALLEY of the alleged manufacturing defect by sending the harness identification code and a detailed description of the problem encountered.

To repair the faulty product, you will need to send it to WOODY VALLEY or authorized individuals.

WOODY VALLEY reserves the right to decide the best method for restoring the harness (repair, replacement of parts, or the entire product).

The warranty does not cover damages resulting from careless or improper use of the product (such as inadequate maintenance, improper storage, overloading, exposure to extreme temperatures, etc.). The same applies to damages caused by accidents, opening shock of the reserve parachute, and normal wear and tear.









8 - HOMOLOGATION CERTIFICATES

rness inspe	ection certificat	e-EN		Harness inspe			
ction certificate number:		Impact pad number:	MISC_289.2024	Inspection certificate number:		Impact pad number:	MISC_289.2024
Manufacturer data				 Manufacturer data			
Manufacturer name: Representative:	Woody Valley srl			Manufacturer name: Representative:	Woody Valley srl Simone Caldana		
Street:	Simone Caldana Via Linz 23			Street	Via Linz 23		
Post code / place: Country:	38121 Trento Italy			Post code / place: Country:	38121 Trento Italy		
				Sample data:			
Sample data:	Harness	Name Impact pad: (1)	Impact pad NAOS FOAM M	 Name:	Harness	Name Impact pad: (1)	Impact pad NAOS FOAM M
ype: lize:	ABS M	Impact pad integrated: (1) Impact pad type:	No Foam	Type: Size:	ABS M	Impact pad integrated: (1) Impact pad type:	No Foam
Veight of Sample [kg]:	4.54	Weight of Sample [kg]: (1)	1	Weight of Sample [kg]:	120	Weight of Sample [kg]: ⁽¹⁾ Serial number: ⁽¹⁾	1 00001
Serial number: Clip-in weight [kg]:	118 0115 001P 120	Serial number: ⁽¹⁾	00001	Serial number: Clip-in weight [kg]: Integrated container for	118 0115 001P 120		
ntegrated container for escue system:	Yes	Date of reception:	29.08.2024	rescue system: (2)	Yes	Date of reception:	29.08.2024
(olume container [cm ³]:	5600 max 1500 min			Volume container [cm ³]:	5600 max 1500 min		
late of reception:	29.08.2024			Date of reception:	29.08.2024		
					107 N		
est report summary	Structual test POSITIVE	Impact pad test POSITIVE		 Test report summary Result:	Structual test POSITIVE	Impact pad test	
Nace	Villeneuve	Villeneuve		Place:	Villeneuve	Villeneuve	
late	10.09.2024	29.08.2024		Date:	10.09.2024	29.08.2024	
ssue data	Villegause			 Issue data	Villeneuve		
lace of declaration: late of issue:	Villeneuve 07.10.2024			Date of issue:	07.10.2024		
lanaging Director: ignature:	Alain Zoller			Managing Director: Signature:	Alain Zoller		
	714			~			
	0				\square		
-	nature approve the validity of the test reports 94						
Air Turquoise SA	has thoroughly tested the sample mentioned a EN1651:2018+A1:2020 [®] and I	bove and certifies its conformity with the	appicable) e following standards:		ature approve the validity of the test reports that has thoroughly tested the sample mentioned	above and certifies its conformity with th	
and and is NOT interested in the last	name it will have independently increasing a set	are and exist a select Perfection of late	encode lossest and is lossest and which a	 	NIL 2-565-20, EN12491:2	1015 and EN1651:1999	
	ness, it will have independently Inspection num be dismounted from the I ⁽²⁾ These standards are NOT covered	harness, e.g. airbag by accreditation D-IS-19457-01		⁽¹⁾ If Impact pad is NOT integrated in the ham be dismounted from the hamest	ess, it will have independently inspection nur s, e.g. airbag. ⁽²⁾ If harness has an integrated	nber, and serial number. Definition of int inner container for emergency parachule	egrated impact pad is impact pad which can n , extra deployment tests are done.
The 03.2022 URQUOISE SA P IU Pré-au-Comte B + CH-IB	144 Villeneuve + +4) (0)2) 955 65	out the written permission of Air Turque	See 24	The of ev 05 04.03.2022 AIR TLIRQUOISE SA P. Route du Pré-au-Comfe B • CH-IB	ARA-TEST.COM 44 Villeneuve + -41 (0)21 965 65	out the written permission of AIR TURO)	INDE 54
The 03.2022 URQUOISE SA P IU Pré-au-Comte B + CH-IB	Page ARA-TEST.COM Add Villenauve * -41(0)2195565	out the written permission of Air Turque	ske2 Ske2 Ske2 Ske2 Ske2 Ske2 Ske2 Ske2 S	The of ev 05 04.03.2022	ARA-TEST.COM	out the written permission of AIR TURO)	iauz Goos sk International State (International State) aragilding by air turque
The 03 2022 URQUOISE SA P U http://www.Comite 8 + CH-18 U http://www.Comite 8 + CH-18 aglider reserve parachulter aglider reserve parachulter	Page ARA-TEST.COM Add Villenauve * -41(0)2195565	out the written permission of Ar Turque	See 24	The of ev 05 04.03.2022 AIR TLIRQUOISE SA P. Route du Pré-au-Comfe B • CH-IB	exertion mut not be reproduced in year with Page ARA-TEST.COM 14 Vitinguove * - 4.1 (DI2) 955 65 aggiden hannesses	n to fi	INDE 54
The 03 2022 URQUOISE SA P Ju P(*au-Contel 8 + CH-18 Ju P(*au-Contel 8 + CH-18 Autoritation (*autoritation) and (*autoritation)	Recention mut not in reproduced a part with Page ARA-TEST.COM Mid Viberneuve - 411(02): 955 65 angliden hamesses b cottoon certificat	out the written permission of Ar Turque	aragilding by air hurq	The of ev 06 04.03.2022 AIR TURQUOISE SA P. Route du Pré-au-Conte 8 + CH-18 Test leboration (for paragliders, par and paraglider reserve parachules	Page ARA-TEST.COM AQUINELY * -41 (0)21 555 55 aquide hameses ction certifical	n to fi	aragiiding by air furque
The 03.2022 URQUDISE SA P Ur Pra-au-Conte (1 - O-Hill Contactor (or propagators, para- pagator reserve paracrute URTPESS INSPEC- ction certificate number: Manufacturer data	exemption mut not be reproduced in part with Page ARA-TEST.COM 442 Vibermouver + -41(102) 955 65 s s exection certificat PH_454.2024	e - EN	aragilding by air hurq	weit (4.43.2222 AIR TLIRQUOISE SA P, Route ou the au-Conte (4 - CH-8) Test sub-order (4 - CH-8)	eastion mut not in reposition in year with Progr 14 Vitingszure + -41 (102) 955 55 aglider harnesses ection certifical PH_454.2024	n of 1 165 te - NfL	aragiiding by air furque
The as associated a CH-Biological Control of the United automatic of the CH-Biological Control of the Control of the CH-Biological Control of the Control of the CH-Biological Control of the Characteristic of the CH-Biological Control of the CH-Biological Control of the CH-Biolog	excention mut not be reproduced in part with Page ARA-TEST.COM 442 Vibernouver + -41(102) 955 65 s s cotion certificat PH_454.2024 Woody Valley srl Simone Caldana	e - EN	aragilding by air hurq	weiti (4.43.2222 AIR TURQUOISE SA P, Route au thé au Contre 8 - CH-8 Test seboard un to paraglicites, para and paraglicite reserve parachutes Hanness inspect Manufacturer data Manufacturer rame: Representative:	eastion nut not be reposited in year with Page ARA-TEST.COM at Vitingsurve + -41 (D21 955 55 applier harnesses ction certifical PH_454.2024 Woody Valley and Simone Caldana	n of 1 165 te - NfL	aragiiding by air furque
the construction of the co	execution nutrition to improve any any set Page ARA-TEST.COM Ind Viberneuve • - 411020: 565 65 oction certificat PH_454.2024 Woody Valley srl	e - EN	aragilding by air hurq	In exe ev (5) (04.03.2022 AIR TURQUCISE SA P. Roure cu Pré-au-Contes (8 - C+HB Test Balondallo (16 progradions, particulation traditional (16 progradions), particulation Handracture data Manufacture mane: Manufacture mane:	ARA-TEST.COM Page ad Vitaneuve + all (D)21 555 55 ection certifical PH_454.2024 Woody Valley srl	n of 1 165 te - NfL	aragiiding by air furque
the construction of the co	ARA-TEST.COM May Valey and Valey and Valey ARA-TEST.COM May Valey and Valey 1955 65 5 5 5 5 5 5 5 5 5 5 5 5 5	e - EN	aragilding by air hurq	weis (o4.03.322) AIR TURQUOISE SA P. Roure ou Price-au-Conte & - CH-IB Roure ou Price-au-Conte & - CH-IB Test Belondon y lar paraglions, po- and abaquidar useriare bandchulet Harneess insages Inspection certificate number: Manufacturer data Manufacturer anne: Representative: Street:	ARA-TEST.COM aq Vilaneuve - 41 (021 355 55 aq Vilaneuve - 41 (021 355 55 ction certificat PH_454.2024 Woody Valley sri Simono Caldana Via Linz 23	n of 1 165 te - NfL	aragiiding by air furque
The saces of the s	Page ARA-TEST.COM MIX Vitement + .4 (128: 956 65 s extra control of the second page of the second s extra control of the second page of the second second of the second page of the second second of the second page of the second page of the second second of the second of the second of the second second of the second of the second of the second second of the second of the second of the second of the second second of the second	e - EN	aragilding by air hurq	We (8) (94.03.2022 AIR TURQUCISE SA P. Route au hr 6 au - Conte & - C - Ha and paesider reserve parachuler Hanness inspec Inspection certificate number: Manufacturer rate Manufacturer rate Brosset Street Pet code place:	ARA-TEST.COM MARA-TEST.COM MA Vilaneuver + - AI (D2) 355 65 applier hannesses Ction certificat PH_454.2024 Woody Caleby srt Simone Caleby srt Simone Caleby and Yia Linz 23 39121 Tronto	n of 1 165 te - NfL	aragiiding by air furque
The stand of the s	execution nut not in reproduced a par vet Page ARA-TEST.COM Max Villemeurve011020;1955 65 5 5 5 5 5 5 5 5 5 5 5 5 5	e - EN Inpact pad number:	MISC_288.2024	weiß (04.03.302) AIR TURQUOISE SA P, Route our hit au Conte B + CH-IB Route our hit au Conte B + CH-IB Test Belonder und en and obergeloter restrict particules,	Page ARA-TEST.COM Ra Vilaneuve41 (D21 555 55 Ction certificar PH_454.2024 Woody Valley arf Simone Caldana Via Linz 33 38121 Trento Italy Harness NAOS	to of the vertice of AN TURG 1 of 1 165 Except of the second of the se	MISC_286.2024
The states of th	execution nutrition in the reproduced in part with repr	e - EN Impact pad represent (*) Mone Impact pad (*) Impact pad represent (*)	MISC_288.2024	we (8) (94.03.2022 AIR TURQUOISE SA P. Route ou Prid-au-Comte (8 + CH-18) Test Baboarton / Ior panagliofits, para and panaglior reserve panadrucket Hannacsture data Manufacturer data Manufacturer data Manufacturer data Manufacturer data Manufacturer data Manufacturer data State: State: State: State: State:	Page ARA-TEST.COM ARAVIENESS CONTRACTION ARAVIENESS CONTRACTION ARAVIENESS CONTRACTION ARAVIENESS CONTRACTION Contract ARAVIENESS ARAVIENESSA	to of the vertice of AN TURG 1 of 1 155 Example 1 156 Instantion of AN TURG 157 Instantio Of AN TURG 157 Instantio Of AN TUR	MISC_285.2024
The stand of the s	Page ARA-TEST.COM AGVINEMENU-VE + -41/D2P.95565 Cection certificat PH_454.2024 Woody Valley srl Simone Caldana Value 2 38121 Trento Ialy Harness NAOS ABS	e - EN Impact pad integrater. ⁽¹⁾	MISC_288.2024	Ver dis (44.0.3202) AIR TURQUCISE SA P. Route auf his au-Conte & - C-HB Traduet auf	ARA-TEST.COM M2Vinetury Al (D2) 355 65 apide harnesses ction certificat PH_464.2024 Woody Valley srt Simone Caldana Via Linz 23 38121 Trento Italy Harness NAOS M4 Harnes NAOS M4 H20 118 015 001P	to the vertice previous of ANT TABLE 165 EVENTS IN TABLE 165 Instantion of ANT TABLE 165 Instantion	MISC_285.2024
The stand of the s	excention nutrition to improve any upper section of the improvement of the improvemen	e - EN Impact paid number: Minna Impact paid number: Minna Impact paid number: Minna Impact paid number: Minna Impact paid number:	MISC_288.2024	we (5) (0.43.3222 AIR TURQUCISE SA P, Roure out his au-Conte & - C-Hai Tard paragrafic the same section of the same sectio	ARA-TEST.COM AR View - 41002135555 AR View - 41002135555 Ction certifical PH_454.2024 Woody Valley erl Simone Caldana Via Linz 23 36121 Trento Laby Harness NAOS MB 120 118 0115 001P 120	et of 1	MISC_288.2024
The stand of the s	ARA-TEST.COM May Valey and Valey and Valey ARA-TEST.COM May Valey and Valey and Valey and Valey ARA-TEST.COM AND	e - EN Impact pad morphologing	MISC_288.2024	Vere version of the second sec	Page ARA-TEST.COM Ra Vilareuve41 (021 355 55 ction certificar PH_454.2024 Woody Valley arf Simone Caldana Via Linz 23 38121 Trento Italy Hamees NAOS ABS M 120 120 120 120 120 120 120 120 120 120	et of 1 et of 1 ef of	MISC_288.2024
The stand of the s	Page ARA-TEST.COM May Valey at vit Page ARA-TEST.COM May Valey at vit Page Pt_454.2024 Woody Valey arf Simonic Caldana Via Linz 23 38121 Trento Tab Hamees Hames NAOS ABS M 4.54 118 015 001P 120 Yes \$500 max \$500 max }	e - EN Impact paid number: Minna Impact paid number: Minna Impact paid number: Minna Impact paid number: Minna Impact paid number:	MISC_288.2024	we (8) (94.93.3022 AIR TURQUOISE SA P, Route ou hit au Conte B + CH-IB Route ou hit au Conte B + CH-IB Test Belocitory Lie parajolistics, para du considior residue back uter Harmachure data Manufacture data Manufacture manie Representative: Street: Perto da Figlion: Contry: Street:	ARA-TEST.COM Page ARA-TEST.COM Activation of the management of	et of 1	MISC_288.2024
The stand of the s	ARA-TEST.COM MIX Viewer + - 41/DB: 955 65 section certificat PH_454.2024 Woody Valley srl Simone Caldana Salt21 Trento Salt21 Trento Harness NAOS ABS M 4.54 113 015 001P 120 Yes	e - EN Impact paid number: Minna Impact paid number: Minna Impact paid number: Minna Impact paid number: Minna Impact paid number:	MISC_288.2024	Vere version of the second sec	ARA-TEST.COM ARA-TEST.COM Ad Viteneuve 40 (C)21 355 65 adjuter harnesses Ction certificat PH_454.2024 Woody Valley arl Simone Caldarna Valley arl Valley arl Simone Caldarna Valley arl Valley arr Valley arl Valley arl Valley arl Valley arl Valley arl Valley arl Valley arr Valley arr Val	et of 1	MISC_288.2024
the 63.3022 URQUIDISE SA P URQUIDISE SA P URQUIDISE SA P URQUIDISE SA P Regulatories and anglider reserve parachule URQUIDISE SINSPEC ction certificate number:	Page ARA-TEST.COM May Valey at vit Page ARA-TEST.COM May Valey at vit Page Pt_454.2024 Woody Valey arf Simonic Caldana Via Linz 23 38121 Trento Tab Hamees Hames NAOS ABS M 4.54 118 015 001P 120 Yes \$500 max \$500 max }	e - EN Impact paid number: Minna Impact paid number: Minna Impact paid number: Minna Impact paid number: Minna Impact paid number:	MISC_288.2024	we (8) (94.93.3022 AIR TURQUOISE SA P, Route ou hit au Conte B + CH-IB Route ou hit au Conte B + CH-IB Test Belocitory Lie parajolistics, para du considior residue back uter Harmachure data Manufacture data Manufacture manie Representative: Street: Perto da Figlion: Contry: Street:	ARA-TEST.COM Page ARA-TEST.COM Activation of the management of	et of 1	MISC_288.2024
The stand of the s	Page ARA-TEST.COM Add Viewerk + -4.010215555 Control Contro Contro Contro Control Contro Control Control Contro Control Con	e - EN Impact pad inspired: (*) Impact pad ins	MISC_288.2024	w (8) (94.03.3022 AIR TURQUCISE SA P, Route au Orife a U-Chef a I - Chef a and paragidar reserve parachuler Inspection certificate number: Manufacture rate Manufacture	ARA-TEST.COM M2 Vibraturer 41 (D21 855 62 M2 Vibraturer 41 (D21 855 62 Ction certifical PH_454.2024 Woody Valley art Stimone Caldama Via Linz 23 38121 Tronto Italy Harness NAGS M3121 Via Ling 01P 120 Yes 5600 max 1500 mn 29.08.2024 Structual test POSITIVE	te of 1	MISC_288.2024
the observed of the second of	ARA-TEST.COM ARAVERST.COM ARAVERST.COM ARAVERST.COM ARAVERST.COM Control Control (Control (Contro	e - EN Impact pad Impact (%) Setai number: Date of reception: Date of reception:	MISC_288.2024	ve 05 (04.03.2022) AIR TURQUCISE SA P. Roure ou Pré-au-Contre 8 - C+HB Test Bacordon (les prançides, par and prançides restrier paracitation Manufacture rame: Representative: Bargel data: Name: Part code (plane: County: Strait: Part code (plane: County: Strait: Part code (plane: County: Strait: Part code (plane: County: Strait: Part code (plane: County: Strait: Diane de recepton: Date of recepton: Test recepton summary	ARA-TEST.COM AQ Vilaneuve + 41 (Q2) 455 65 AQ Vilaneuve + 41 (Q2) 455 65 Ction certificat PH_454.2024 Woody Valley erl Simone Caldama Via Linz 23 38121 Trento Laby Harness NAOS M AOS M 20 118 0115 001P 120 Yes 500 min 29.08.2024	et of 1 effort and the permission of ANT TURG effort and the permissio	MISC_288.2024
The standing of the standing o	ARA-TEST.COM ARAVEST.COM ARAVEST.COM ARAVEST.COM ARAVEST.COM ARAVEST.COM PL_454.2024 Woody Valley srl Simone Caldana Via Linz 23 38121 Trento Italy Hamess NAOS ARS ARS ARS ARS ARS ARS ARS AR	e - EN Impact pad inter- inter	MISC_288.2024	ve (8) (04.0.3222 AIR TURQUOISE SA P, Route du Pid-au-Comte 8 + CH-88 Route du Pid-au-Comte 8 + CH-88 Inspection certificate number: Manufacture rata: Representative: Street: Peter code / pizze: Contry: Street: Page 10 Sample (pizze: Contry: Street: Pizze (P) Street: Pizze (P) Street: Street: P) Street: P) Street: P) Street: S	ARA-TEST.COM AQVieneuve + -41 (D)21 355 65 AQVieneuve + -41 (D)21 355 65 PH_454.2024 Woody Valley arl Simonic Caldana Valley Harness NAOS ABS Harness NAOS ABS 120 118 of 15 00 IP 120 Yes 5600 max 1500 min 29.08.2024	et of 1 effective permission of ANT TURG effective permission of A	MISC_288.2024
The second secon	ARA-TEST.COM ARAVEST.COM ARAVEST.COM ARAVEST.COM ARAVEST.COM ARAVEST.COM PL_454.2024 Woody Valley srl Simone Caldana Via Linz 23 38121 Trento Italy Hamess NAOS ARS ARS ARS ARS ARS ARS ARS AR	e - EN Impact pad inter- inter	MISC_288.2024	ve (8) (04.0.3222 AIR TURQUOISE SA P, Route du Pid-au-Comte 8 + CH-88 Route du Pid-au-Comte 8 + CH-88 Inspection certificate number: Manufacture rata: Representative: Street: Peter code / pizze: Contry: Street: Page 10 Sample (pizze: Contry: Street: Pizze (P) Street: Pizze (P) Street: Street: P) Street: P) Street: P) Street: S	ARA-TEST.COM AQVieneuve + -41 (D)21 355 65 AQVieneuve + -41 (D)21 355 65 PH_454.2024 Woody Valley arl Simonic Caldana Valley Harness NAOS ABS Harness NAOS ABS 120 118 of 15 00 IP 120 Yes 5600 max 1500 min 29.08.2024	et of 1 effective permission of ANT TURG effective permission of A	MISC_288.2024
The second secon	excertion nutrities reproduced a par vet Page ARA-TEST_COM MA Viewerve + -4 IOE:1565.65 ection certificat PH_454.2024 Woody Valley srl Simone Caldana Valley srl Simone Caldana Valley srl Simone Caldana Valley Harness NAOS ASS M 4.54 118 of 15 00 P1 120 Yes Section certification Caldana MACS M 4.54 118 of 00 P1 120 Yes Section certification Caldana M 4.54 1500 min 28.08.2024 Section caldana Villenceve Villenceve	e - EN Impact pad inter- inter	MISC_288.2024	Verdi (d. 63.3222)	ARA-TEST.COM AR Viennuve 41 (CR) 1955 65 AR Viennuve 4	et of 1 st	MISC_288.2024
the of a source of the source	ARA-TEST.COM Ind Vibereuve 41/02P 1955 65 Section certificat PH_454.2024 Woody Valley srl Simone Caldana Via Linz 23 38121 Trento Iaay Hames NAOS ABS ASS 4.54 118 015 001P 120 Yes S600 max 29.98.2024 Structual test POSITVE Villeneuve 10.09.2024	e - EN Impact pad inter- inter	MISC_288.2024	Verdis (p. 4.3. 3222)	ARA-TEST.COM AQVIENDEVT + -411021355 65 AQVIENDEVT + -41	et of 1 st	MISC_288.2024
the of a source of the source	ARA-TEST.COM ARA-TEST.COM Ad Viewer + - 4.0128:5555 Section certificat PH_454.2024 Woody Valley srl Simone Caldana Via Linz 23 33121 Trento Italy Harnes NACS AR H 4.54 118 0115 001P 120 Yes Sector max 1500 min 29.08.2024 Brucctual test POSITIVE Villeneuve 10.08.3024	e - EN Impact pad inter- inter	MISC_288.2024	Vere (8) (94.03.2022 AIR TURQUCISE SA P. Route auto his au-Conte & - C-HB Tarlow auto his au-Conte & - C-HB Tarlow auto his auto-conte & - C-HB Tarlow auto his auto-conte & - C-HB Tarlow auto-conte & - C-HB	ARA-TEST.COM M2 Vilencever M2 Vilencever M2 Vilencever M2 Vilencever M2 Vilencever M3 Vilencever M4 Vilencever M3 Vilencever M4 Vilencever 120 min 29.08.2024 Structual text POSITIVE Vilencever 10.09.2024	et of 1 st	MISC_288.2024
the of a source of the source	ARA-TEST.COM ARA-TEST.COM Ad Viewer + - 4.0128:5555 Section certificat PH_454.2024 Woody Valley srl Simone Caldana Via Linz 23 33121 Trento Italy Harnes NACS AR H 4.54 118 0115 001P 120 Yes Sector max 1500 min 29.08.2024 Brucctual test POSITIVE Villeneuve 10.08.3024	e - EN Impact pad inter- inter	MISC_288.2024	Verdis (p. 4.3. 3222)	ARA-TEST.COM M2 Vilencever M2 Vilencever M2 Vilencever M2 Vilencever M2 Vilencever M3 Vilencever M4 Vilencever M3 Vilencever M4 Vilencever 120 min 29.08.2024 Structual text POSITIVE Vilencever 10.09.2024	et of 1 st	MISC_288.2024
The stand of the s	ARA-TEST.COM ARA-TEST.COM Ad Viewer + - 4.0128:5555 Section certificat PH_454.2024 Woody Valley srl Simone Caldana Via Linz 23 33121 Trento Italy Harnes NACS AR H 4.54 118 0115 001P 120 Yes Sector max 1500 min 29.08.2024 Brucctual test POSITIVE Villeneuve 10.08.3024	e - EN Impact pad inter- inter	MISC_288.2024	Verdis (p. 4.3. 3222)	ARA-TEST.COM M2 Vilencever M2 Vilencever M2 Vilencever M2 Vilencever M2 Vilencever M3 Vilencever M4 Vilencever M3 Vilencever M4 Vilencever 120 min 29.08.2024 Structual text POSITIVE Vilencever 10.09.2024	et of 1 st	MISC_288.2024
The second secon	ARA-TEST COM ARA-TEST COM ARA Viseous + .4.01021 955 55 Section certificat PH_454.2024 Woody Valley srl Simone Catalogue PH_454.2024 Woody Valley srl Simone Catalogue Simone Catalogue NACS NACS NACS MACS MACS MACS Section Section 115 017 120 Section Section Section Section Section Section Section Section Section Section Section Section Section Section Section Section Se	e - EN impact pad read: (************************************	Impact pad NAOS INFLATABLE M No Inflatable Odol 29.08.2024	Verilia (JA 19.3.322)	ARA-TEST.COM M2 Vilencever M2 Vilencever M2 Vilencever M2 Vilencever M2 Vilencever M3 Vilencever M4 Vilencever M3 Vilencever M4 Vilencever 120 min 29.08.2024 Structual text POSITIVE Vilencever 10.09.2024	te of 1	Impact pad NACS INFLATABLE M No Inflatable Odd S28.0224
the second secon	Page ARA-TEST.COM And Viewerker + - 41/DP/55555 CECTION CERTIFICAT PH_454.2024 PH_454.2024 Woody Valley and Simone Calaba Via Linz 23 Sali21 Trento Taily Hamees NAOS N AOS N AOS N SIGNITICATION SIGN	e - EN impact pad read: (************************************	Impact pad NAOS INFLATABLE M No Inflatable Odol 29.08.2024	ve 08 (04.0.322) AIR TURQUOISE SA (P. R Rave du Piñe au Comte 8 + CH-B Test Bachola y les paraglions, para du bagodin reserve bachoute Inspection and the same comte and Manufacture rame: Representative: Bane Code (pinor: Contry: Strat: Para Code (pinor: Contry: Strat: Para Code (pinor: Contry: Strat: Para Code (pinor: Contry: Strat: Para Code (pinor: Contry: Data of sample (para: Data of seception: Data of secept	ARA-TEST.COM ARV-TEST.COM Ad Viteoreuve 4) (DEI 365 62 adjider hamesses PH_454.2024 Woody Valley arl Sins Linz Catama Sing Linz	At the within permission of ANT TABLE 165 EVENT ANT TABLE 165 INFORMATION OF ANT TABLE 166 INFORMATION OF ANT TABLE 167 INFORMATION OF ANT TABLE 168 INFORMATION OF ANT TABLE 168 INFORMATION OF ANT TABLE 169 IN	Impact pad
The second secon	ARA-TEST COM ARA-TEST COM ARA Viseous + .4.01021 955 55 Section certificat PH_454.2024 Woody Valley srl Simone Catalogue PH_454.2024 Woody Valley srl Simone Catalogue Simone Catalogue NACS NACS NACS MACS MACS MACS Section Section 115 017 120 Section Section Section Section Section Section Section Section Section Section Section Section Section Section Section Section Se	e e EN Ingest pad insgrade (*) Ingest pad insgrade (*) Serial nomber:*) Date of reception: Ingest pad insgrade (*) Uterent in school (*) Ingest pad insgrade (*) Ingest pad in	Antos INFLATABLE M MISC_288.2024 Impact pad MISC_288.2024 Impact pad MAGOS INFLATABLE M MO 0.041 28.08.2024	ve (8) (9.4.9.3222 AR TURQUCISE SA P. Route au Orité au Contre I - C-their Tardo caesquere a contre I - C-their Tardo caesquere estave paractives Inspection conflication number: Manufacturer data Manufacturer data Manufacturer data Manufacturer data Manufacturer data Manufacturer data Manufacturer data Manufacturer data Manufacturer data Manufacturer data Stoate Representation paractives Stoate Representation Stoate Stoate Manufacturer data Manufacturer data Manufacturer data Manufacturer data Stoate Representation Stoate Stoate Data of receptor: Test report summary Manufacturer: Data of receptor: Stoate Manufacturer: Stoate Stoate Manufacturer: Stoate Sto	ARA-TEST.COM ARA VIEWS 40 (CR) 1955 65 ARA VIEWS 40	An and the permanent of AN TURG and a set of 1 To a set of 1 The set	Impact pad MISC_285.2024 Impact pad NAOS INFLATABLE M No Monoble 1041 23.05.2024

WoodyValley _____

Carabiner height	S = 42 cm M = 44 cm		
	L = 46 cm XL = 47,5 cm		
Distance between carabiners	S = 37-43,5 cm M = 37-44,5 cm		
(min. max.)	L = 37-47 cm XL = 37- 49 cm		
Total weight of NAOS size M	4,35 kg FOAM		
	3,80 kg INFLATABLE		
Dorsal protection type	FOAM - INFLATABLE		
Harness Type	T-LOCK		
Reserve parachute container	Under-leg container		
emergency	with side handle		
Storage volume of	1500 – 5600 cm ³		
reserve parachute			
Usage limit	120 daN		
Homologation number	PH_454.2024		

9- TECHNICAL DATA

Every effort has been made to ensure that the information provided in this manual is accurate, but please note that it is intended solely as a guide. This user's manual is subject to change without prior notice. Please check at www.woodyvalley.com for the latest information regarding the NAOS harness.

Last updated: NOVEMBER 2024